
Mainstream Liquid Cooler Installation Guide – TR4/TR5

1. INSTALL 4 PCS. STANDOFFS TO CPU SOCKET

Tighten the standoffs until the shoulder on the M3.5 thread contacts the threaded studs on the CPU socket.





Standoff x4 pcs. (TR4/sTRX4/SP3)

or


Standoff x4 pcs. (TR5/sTRX5/SP6/ sWRX8/9)

2. INSTALL THE LCS ON THE CPU

Remove the TIM protection Cap from the LCS. Position the LCS onto the CPU via guidance on the 4 pcs. standoffs.




3. INSERT 4PCS. SPRINGS



4. INSERT 4 PCS. THUMBNUTS

Screw 4 pcs. thumbnuts onto the threaded standoffs.




Step #1:
hand tighten all 4 pcs. thumbnuts.

Step #2:
Tighten the 4 pcs. thumbnuts in a cross-pattern sequence to equally torque (Nm).

Mainstream Liquid Cooler Installation Guide – TR4/TR5

5. MOUNTING THE RADIATOR & FANS

- Install the fans on the radiator with the provided UNC 6-32, 34mm screws.
- Mount the radiator (attached with fans) onto the case with the UNC 6-32, 5mm screws and washers.




UNC 6-32, 34mm screws

UNC 6-32, 5mm screws

Washer

6. CONNECTING THE PUMP POWER CABLE

Connect the pump power cable to a fan header on the motherboard.



REGULATORY INFORMATION & SAFETY

FCC Part 15.107 & 15.109

- EMC
  - EN-55032: 2015
  - EN-55035: 2017
  - EN-61000-3-2: 2014
  - EN-61000-3-3: 2013
- ICES 003 issue 6 from January 2016


CAUTION:

- Maximum ambient temperature: 50° C
- Maximum normal operating temperature of coolant: 60° C
- This equipment is intended for use inside an enclosed personal computer. This equipment is not suitable for use in locations where it is operating outside of enclosed computer chassis and where children are likely to be present.

Workstation Liquid Cooler Installation Guide – Xeon


1. PREPARE THE PUMP

Remove the protective cover, inspect the TIM, and unlock the lock latches.




2. POSITION THE PUMP


Align the pump with the CPU socket and lower it into place.



3. SECURE THE LOCK LATCHES

Engage the four lock latches in sequence (1 → 2 → 3 → 4), as indicated on the pump cap.






Workstation Liquid Cooler Installation Guide – Xeon

4. TIGHTEN THE MOUNTING NUTS


Using a T30 Torx screwdriver, tighten the four nuts in sequence (1 → 2 → 3 → 4). Reverse the sequence for removal.






5. MOUNTING THE RADIATOR & FANS

- Install the fans on the radiator with the provided UNC 6-32, 34mm screws.
- Mount the radiator (attached with fans) onto the case with the UNC 6-32, 5mm screws and washers.



6. CONNECTING THE PUMP POWER CABLE

Connect the pump power cable to a fan header on the motherboard.



REGULATORY INFORMATION & SAFETY

IEC/UL 62368-1:2014

EMC

- EN 55032:2015, Class B
- EN 55035:2017
- FCC 47 CFR, Part 15, Subpart B, Class B
- ICES-003, Issue 6:2016, Class B

CAUTION:

- Maximum ambient temperature: 50° C
- Maximum normal operating temperature of coolant: 60° C
- This equipment is intended for use inside an enclosed personal computer. This equipment is not suitable for use in locations where it is operating outside of enclosed computer chassis and where children are likely to be present.

Document number: 60-305-0000008