
## 6. CONNECT FAN CABLE
Lüfterkabel anschließen | Connectez le câble du ventilateur | Conectar el cable del ventilador | 连接风扇电缆

### LINQ6 FAN CABLE
LINQ6 Lüfterkabel | Câble de ventilateur LINQ6 | Cable de ventilador LINQ6 | LINQ6 风扇电缆




**LINQ6 EXTENSION CABLE**
LINQ6-Erweiterung | Extension LINQ6 | Extensión LINQ6 | LINQ6 延长线


**Controller is needed for D-RGB functions.**
Für D-RGB-Funktionen ist ein Controller erforderlich.
Un contrôleur est nécessaire pour les fonctions D-RGB.
Se necesita un controlador para las funciones D-RGB.
D-RGB 需要控制器以使用D-RGB功能

OPTIONAL: **LINQ6 ADAPTER**
Optional: LINQ6-Adapter | En option: adaptateur LINQ6 | Opcional: Adaptador LINQ6 | 可选项: LINQ6 转接线




**²IMPORTANCE NOTICE**
Follow mainboard manual for instructions on D-RGB control.
Befolgen Sie für Anweisungen zur D-RGB-Steuerung das Motherboard-Handbuch.
Suivez le manuel de la carte mère pour obtenir des instructions sur le contrôle D-RGB.
Siga el manual de la placa base para obtener instrucciones sobre el control D-RGB.
按照主板手册了解 D-RGB 控制说明。

## 7. INSTALL SCREW COVERS
Schraubenabdeckungen anbringen | Installer les cache-vis | Instalar cubiertas de tornillos | 安装螺丝盖




## SUPPORT & WARRANTY
Support und Garantie | Assistance et garantie | Soporte y garantía | 支持和保修

**EN** As a Phanteks customer, you are priority number one for us. We have a dedicated team across the globe to deliver the experience you deserve. If you have any issues with the products, please don't hesitate to contact our customer care team.

**DE** Als Phanteks-Kunde haben Sie für uns oberste Priorität. Wir haben ein engagiertes Team auf der ganzen Welt, das Ihnen das Erlebnis bietet, das Sie verdienen. Wenn Sie Probleme mit den Produkten haben, zögern Sie bitte nicht, unser Kundendienstteam zu kontaktieren.

**FR** En tant que client Phanteks, vous êtes la priorité numéro un pour nous. Nous disposons d'une équipe dédiée à travers le monde pour vous offrir l'expérience que vous méritez. Si vous rencontrez des problèmes avec les produits, n'hésitez pas à contacter notre équipe de service client.

**ES** Como cliente de Phanteks, usted es la prioridad número uno para nosotros. Contamos con un equipo dedicado en todo el mundo para brindarle la experiencia que se merece. Si tiene algún problema con los productos, no dude en ponerse en contacto con nuestro equipo de atención al cliente.

**CN** 作为 Phanteks 客户，您是我们的第一要务。我们在全球拥有一支专业团队，为您提供应有的体验。如果您对产品有任何问题，请随时联系我们的客户服务团队。

**RMA and Technical Support Americas**
**Hours:** Monday-Friday 9:00-5:00 PST
**Phone number:** +1(909)598-2115
**Email:** support@phanteksusa.com
**Facebook:** @Phanteks

**RMA and Technical Support International**
**Email:** support@phanteks.com
**Facebook:** @Phanteks

**For spare parts and optional upgrades please visit:**
www.axpertec.com (EU) | www.phanteksusa.com (US)

**5 YEARS WARRANTY**

## SAFETY INFORMATION
SICHERHEITSINFORMATION | INFORMATION DE SÉCURITÉ | INFORMACIÓN DE SEGURIDAD | 安全信息

**In order to achieve maximum safety, we suggest that you adopt the following guidelines:**

1. Place the product on a clean and stable surface that allows adequate air ventilation.
2. Don't use or place the product and any of its components near water, moisture, or other wet surfaces; or place the product near any heat, open flame, or other hot surfaces such as radiators, stoves, fireplaces, and candles.
3. Use caution when operating the desktop PC to avoid electrical shock or damage, such as unplugging the power supply during thunderstorms, ensuring that your hands are dry before using (and handling) the desktop PC, keeping it away from any source of liquid and/or heat source, and using all other reasonable precautions needed under the circumstances.
4. When connecting external devices to your desktop PC, carefully plan how the wires will be placed. Protect any connected cables from being trod on or pinched, particularly at plugs, convenience receptacles, or the point where they exit from.
5. Take extra caution when handeling/removing/reattaching glass components. Once removed, place the glass component on a stable surface first before proceeding.
6. When unplugging any connected devices and/or cables, always pull the cable or device's plug or connector. Don't forcefully tug on its cord.
7. Don't place any heavy items on top of the product.
8. Make sure that the desktop PC is off, unplugged from the outlet, and that all connected devices are powered off and unplugged (if any) before installing or uninstalling any internal component to and/or from the dekstop PC or product.




**NOTE ON DISPOSAL**

The **WEEE symbol** indicates that this product must not be disposed of with normal household waste. Through the correct disposal of this product, you will help protect the environment. For more information on the disposal of this product, please contact your local municipality, your waste disposal service or the shop where you purchased the product.

**Phanteks Taiwan Inc.**
11F., No. 150, Jian 1st Rd.,
Zhonghe Dist.
New Taipei City 235

**Importer EU**
Axpertec Int. B.V. (EU)
Sydneystraat 33
3047 BP Rotterdam
The Netherlands

**Importer US**
Axpertec Inc. (US)
20465 E Walnut Dr. N
City of Industry, CA 91789
USA



GLACIER ONE M25G2
INSTALLATION GUIDE
Installationsanleitung | Guide d'installation | Guía de instalación | 安装指南

Ausführung | Version | Versión | 版本 | Version 1.1

## THIS MANUAL IS FOR THE FOLLOWING MODELS
Dieses Handbuch gilt für die folgenden Modelle | Ce manuel concerne les modèles suivants | Este manual es para los siguientes modelos | 此手册适用于以下型号

| | | |
|---|---|---|
| **PH-GO360M25G2_DBK02** | Glacier One M25-360 G2 | Black |
| **PH-GO360M25G2_DWT02** | Glacier One M25-360 G2 | White |

**LEGEND**
Legende | Légende | Leyenda | 说明

Remove | Entfernen | Retirer | Eliminar | 移除
Install | Installieren | Installer | Instalar | 安装
Loosen | Lösen | Desserrer | Aflojar | 拧松


**EN** *Phanteks will not take responsibility for any damages incurred due to incorrect installation or usage of this product.*

**DE** *Phanteks übernimmt keine Verantwortung für Schäden, die durch eine falsche Installation oder Verwendung dieses Produkts entstehen.*

**FR** *Phanteks décline toute responsabilité en cas de dommages résultant d'une installation ou d'une utilisation incorrecte de ce produit.*

**ES** *Phanteks no se responsabilizará de los daños ocasionados por la instalación o el uso incorrectos de este producto.*


**CN** *Phanteks* 不会对安装中失误造成的任何损失负责，请仔细阅读本手册。




**Online Manual**
Online-Handbuch
Manuel en ligne
Manual en Línea
在线手册

## SCOPE OF DELIVERY
Lieferumfang | Contenu de la livraison | Alcance de la entrega | 供货范围

### GLACIER ONE M25 GEN2



Radiator
**M25** Gen2 Fans

### MOUNTING HARDWARE
Montagezubehör | Le matériel de montage | Accesorios de montaje | 安装硬件


**AM4 | AM5 Stand-off**
x4


**Intel 2011 | 2066 Stand-off**
x4


**Intel 115X | 1200 Stand-off**
x4


**TR4 Stand-off**
360 Models only
x4


**Intel 1700 Stand-off**
x4


**Thumb Nuts**
x4


**Radiator Screws**
6 mm | 6-32 UNC
x12[1]


**Radiator Screws**
30 mm | 6-32 UNC
x12[1]


**Tube Clips**
x3



**SATA to 2-PIN Pump Adapter**
x1




**PH-NDC Thermal Compound**
x1



**Intel 115X | 1200 | 1700 Backplate**
x1


**AMD AM4 | AM5 Bracket**
Intel bracket is pre-installed
x1


**AMD TR4 Bracket**
360 Models only
x1


### ACCESSORIES
Zubehör | Accessoires | Accesorios | 配件


**LINQ6 Extension Cable**
500 mm
x1


**LINQ6 Adapter**
500 mm
x1




**Screw Cover Corners**
Left | Right
x2[1] | x2[1]



**Screw Cover Bridge**
x4[1]

**[1]IMPORTANCE NOTICE**
Quantity may vary on radiator size.
Die Menge kann je nach Heizkörpergröße variieren.
La quantité peut varier selon la taille du radiateur.
La cantidad puede variar según el tamaño del radiador.
数量可能根据散热器尺寸而变化。

## 1. PREPARE MAINBOARD
Mainboard vorbereiten | Préparer la carte mère | Preparar la placa base | 准备主板

### INTEL 115X | 1200 | 1700
PROCEED TO STEP 2.




INSTALL
115X | 1200 STAND-OFF 4x



INSTALL
1700 STAND-OFF 4x



**ATTENTION**
Check the stand-off texture to make sure you got the correct socket stand-off.





DE Überprüfen Sie die Abstandshalterstruktur, um sicherzustellen, dass Sie den richtigen Sockelabstandshalter haben.

FR Vérifiez la texture de l'écartement pour vous assurer que vous avez obtenu l'écartement correct de la douille.


ES Verifique la textura del separador para asegurarse de obtener el separador de enchufe correcto.

CN 检查支架纹理，确保您获得正确的插座支架。


### INTEL 2011 | 2066
PROCEED TO STEP 2.





INSTALL
2011 | 2066 STAND-OFF 4x




### AMD AM4 | AM5
PROCEED TO STEP 2.









### AMD TR4
PROCEED TO STEP 2.










GLACIER ONE M25G2
INSTALLATION GUIDE
Installationsanleitung | Guide d'installation | Guía de instalación | 安装指南

## 2. INSTALLING CPU BLOCK
CPU-Block installieren | Installation du bloc CPU | Instalación del bloque de CPU | 安装 CPU 块


### SECURE CPU BLOCK
Linke Seitenwand | Panneau latéral gauche | Panel lateral izquierdo | 左侧面板



INSTALL
THUMB NUTS 4x



### FUTURE INSTALLATION: APPLY THERMAL PASTE
Linke Seitenwand | Panneau latéral gauche | Panel lateral izquierdo | 左侧面板




**PRO TIP**
The thermal compound is pre-applied. More thermal compound is included for future installations.


DE Die Wärmeleitpaste ist bereits aufgetragen. Für spätere Installationen ist mehr Wärmeleitpaste im Lieferumfang enthalten.

FR La pâte thermique est pré-appliquée. Plus de pâte thermique est incluse pour les installations futures.


ES El compuesto térmico está precalicado. Se incluye más compuesto térmico para futuras instalaciones.

CN 导热膏已预先涂抹。包含更多导热膏以供将来安装。


## 3. MOUNT THE RADIATOR AND FANS
Montieren Sie den Kühler und die Lüfter | Montez le radiateur et les ventilateurs | Monte el radiador y los ventiladores | 安装散热器和风扇




**PRO TIP**
Step 7. Install Screw Covers.




## 4. INSTALL TUBE CLIPS
Rohrschellen montieren | Installer les clips pour tubes | Instalar clips de tubo | 安装管夹




## 5. CONNECT PUMP MODULE
Pumpenmodul anschließen | Connecter le module de pompe | Conecte el módulo de bomba | 连接泵模块

### PUMP CABLES
Pumpenkabel | Câbles de pompe | Cables de bomba | 泵电缆

