
PHANTEKS


AMP BH



ACCESSORIES INCLUDED

Accessories Included
User Manual
Installation Guide
PSU Bag
Cable Bag
Ziptie Bag
Screw Pack


POWER SUPPLY AMP GH




MANUAL WARRANTY



CABLE BAG



ZIP TIE BAG




SCREW PACK



CABLES INCLUDED

MOTHERBOARD 24-PIN




CPU 4+4-PIN



12V-2X6 12+4-PIN



C13 POWER CABLE



PCIe 6+2-PIN



SATA | MOLEX



Cable Type	Connectors per Cable	Length per Cable(mm)
Motherboard 24-PIN	1	650
CPU EPS 4+4-PIN	1	700
PCIe 6+2-PIN	2 | 1	700 | 120
12V-2x6 12+4-PIN	1	720
SATA | Molex	3	550 | 150 | 150
C13 Power Cable	1	1500

** The amount of cables may vary depending on model.*

INSTALLATION GUIDE SUPPORTS

PH-P650BH_01
PH-P750BH_01
PH-P850BH_01

80 PLUS BRONZE

FOLLOW US ON
SOCIAL MEDIA

Instagram
Phanteks

Facebook
Phanteks

YouTube
Phanteks

Twitter
@phanteks


SUPPORT

US & Canada
support@phanteksusa.com

International
support@phanteks.com

01 INSTALL PSU INTO CHASSIS


Secure the power supply with the 4x included PSU screws. Check the PC chassis manual for more installation details.



PRO TIP
Pre-connect all needed cables to the PSU before installing it into the chassis.
See step 2

02 CONNECT CABLES TO SYSTEM COMPONENTS

Connect all power cables to the corresponding system components, please follow the manufacturers instructions for additional information.




** The amount of cables may vary depending on model.*

03 12V-2X6 GPU CONNECTOR

The AMP BH 750 is equipped with the 12V-2x6 PCIe Gen5.1 GPU connector and cable. **Note that a compatible GPU is required.**

The maximum power output depends on your AMP GH model:



AMP Model	Output Watts
BH 1200	Up to 600
BH 1000	Up to 600
BH 850	Up to 450
BH 750	Up to 450
BH 650	Not available

04 CONNECT POWER CABLE

Connect the power cable to the power supply and a grounded power outlet respectively. Make sure the power supply is turned off **'O'** before connecting it to a power outlet.



05 BE SAFE!

Switch the power button to the **'I'** position to turn on your system.

When making any changes to the hardware, be sure that the power button is switched from the **'I'** to the **'O'** position so the power supply is turned off.

Only use Phanteks cables that are provided with the power supply. If there are any questions, please don't hesitate to visit www.phanteks.com/FAQ for more details.

Phanteks will not take responsibility for any damages incurred due to incorrect installation or usage of this product.